



FRONT



FRONT RIGHT



BACK



BACK LEFT

A1-2....BI-TORQ ACTUATOR, PN75SR WITH OASIS BALL VALVE, BV706-4N6LDDN  
 BV1,2...OASIS BALL VALVE, BV706-4N6LDDN  
 CV1,2...OASIS CHECK VALVE, CV304-6NXDN  
 CIB.....TGT CUSTOMER INTERFACE BOARD  
 F1.....FILTER, PARKER JN4D-CP, ELEMENT P/N 4CJDK  
 F2.....FILTER, PARKER JN4D-10CP ELEMENT P/N 10CJDK


M1.....METER, ENDRESS+HAUSER CNGMASS DN25 FLOW METER TRANSMITTER/SENSOR  
 NV1-4..NOSHOK NEEDLE VALVE, 152MCF  
 PS1,2..PRESSURE SWITCH, NASON  
 PSIG1..PRESSURE GAUGE, TGT 0-6000 PSI  
 PT1,2..MURPHY TRANSDUCER, PXT-K  
 RV1,2..MERCER RELIEF VALVE, 1400 Series  
 SV1-2..RED HAT SOLENOID VALVE



NZ1



BB



DB




NZ2

PSIG




VLB

ILB




AND

MMI



CIB



MB

- AND....ALPHA-NUMERIC DISPLAY,  
4 LINE X 40 CHAR., DCI404AF3BW6
- BB.....TGT BREAKAWAY BASE
- CIB....CUSTOMER INTERFACE BOARD,  
TGT 23005
- DB.....DISPLAY BOARD, 23002
- ILB....TGT-6ILB IN-LINE BREAKAWAY
- ILB1...OPW BREAKAWAY P/N ILB-5
- MMI...MAN-MACHINE INTERFACE BOARD, TGT 23007
- MB....MAIN BOARD, TGT 23004
- NZ1....OPW NOZZLE, CT5000
- NZ2....OPW NOZZLE, CT1000
- PSIG...WIKA 0-6000 PRESSURE GAUGE, SS,  
8992945-0012
- VLB....TGT VENT-LINE BREAKAWAY
- 3WV....PARKER 3-WAY VALVE, 4F-HB4XPKR-SSP



ILB1