

# LED Definition

HOSE #1	TERMINAL (#)	HOSE #2	TERMINAL (#)
ED2	BANK 1 (80)	ED6	BANK 1 (80)
ED3	BANK 2 (82)	ED7	BANK 2 (82)
ED4	BANK 3 (83)	ED8	BANK 3 (83)
ED5	RESET COMPLETE (8)	ED9	RESET COMPLETE (8)
ED28	AUTHRIZE INPUT (14)	ED29	AUTHRIZE INPUT (14)
ED26	OVER PSI SWITCH	ED27	OVER PSI SWITCH
ED22	STOP BOTTON & HOLSTER	ED24	BOTTON & HOLSTER
ED23	START BOTTON	ED25	START BOTTON
ED20	PULSE INPUT	ED21	PULSE INPUT
ED19	PULSA OUTPUT	ED18	PULSE OUTPUT

## ED's that must be on before it will go to RESET COMPLETE (8s then 0s)

HOSE #1 IS ED28, ED26 and ED22

HOSE #2 IS ED29, ED27 and ED24

