

PINS	1	2	3	4	5	PINS
7	1	2	3	YES	CREDIT	7
8	4	5	6	NO	DEBIT	8
9	7	8	9	ALPHA	CASY	9
10	CANCEL	0	CLEAR	HELP	ENTER	10
PINS	1	2	3	4	5	PINS